



# AIR ARMS

## Users Handbook

THIS HANDBOOK REFERS TO S510 XS ULTIMATE SPORTER HIGH POWER MODELS



PLEASE READ THIS MANUAL BEFORE USING YOUR NEW RIFLE, IT  
CONTAINS IMPORTANT SAFETY INFORMATION AND INSTRUCTION ON  
ADJUSTMENT AND MAINTENANCE.



# Contents

<b>Gun Security</b>	<b>1</b>	<b>Stock Adjustments</b>	<b>15</b>
<b>Serial Number</b>	<b>1</b>	<b>Cheek Piece</b>	<b>15</b>
<b>Safety First</b>	<b>2</b>	<b>Sling Studs</b>	<b>15</b>
<b>Contents Of The Box</b>	<b>2</b>	<b>Butt Pad</b>	<b>16</b>
<b>Important Information</b>	<b>2</b>	<b>Removing The Stock</b>	<b>16</b>
<b>Operating Instructions</b>	<b>5</b>	<b>Exploded Diagrams</b>	<b>17</b>
<b>Cocking</b>	<b>5</b>	<b>Warranty (UK Only)</b>	<b>24</b>
<b>Mounting/demounting the Magazine &amp; Pellets</b>	<b>6</b>		
<b>Demounting</b>	<b>6</b>		
<b>Loading Pellets</b>	<b>6</b>		
<b>Trigger Adjustments</b>	<b>7</b>		
<b>Description Of Operation</b>	<b>7</b>		
<b>Adjustment</b>	<b>8</b>		
<b>Power Adjuster</b>	<b>10</b>		
<b>Filling Instructions</b>	<b>11</b>		
<b>Maintenance</b>	<b>13</b>		
<b>Fixings</b>	<b>13</b>		
<b>Barrel</b>	<b>13</b>		
<b>Lubrication</b>	<b>14</b>		

*AIR ARMS RESERVE THE RIGHT TO ALTER THE CONSTRUCTION, APPEARANCE OR PERFORMANCE OF ANY PRODUCT WITHOUT PRIOR NOTIFICATION. ALL ILLUSTRATIONS ARE FOR INFORMATION PURPOSES ONLY AND DO NOT NECESSARILY SHOW THE EXACT MODEL THAT WAS PURCHASED.*

## Gun Security

It is important to make sure that your gun is always kept in a safe and secure fashion when not in use.


For rifles purchased in the UK and that are NOT FAC rated (high power) a free gun lock and mounting eyes are supplied. Please follow the simple fixing instructions and keep our sport safe.

**Note: If there is no gun lock in the box please contact the dealer you purchased the rifle from.**



## Serial Number

When corresponding with Air Arms please quote the serial number of your rifle.



## Safety First

- Always treat your air rifle or pistol as if loaded. Never assume it is clear. CHECK.
- When first picking an air rifle or pistol up, check to make sure it is not cocked or loaded.
- Never leave your rifle or pistol cocked or loaded.
- Never leave a cocked or loaded rifle or pistol unattended.
- Always point your rifle or pistol in a safe direction. Never point the gun at anyone.
- Always know the back drop to your shooting. Make sure you know where your pellets are going.
- Be aware of ricochets.
- Always conduct yourself in a sports-man like manner.

Be aware that your actions will be under the scrutiny of other members of the public who may not share your enthusiasm for air gun shooting. Bad practises promote bad publicity. Do not jeopardise your future enjoyment by misusing this rifle.

## Contents Of The Box

- S51 XS Ultimate Sporter rifle
- 1 x Manual
- 1 x Tool kit containing.
  - 1 x 1.5 mm allen key
  - 1 x 2.5 mm allen key
  - 1 x 3 mm allen key
  - 1 x 4 mm allen key
  - 1 x S475 Filling adaptor

## Important Information

***WARNING! - UNAUTHORISED DISASSEMBLY OF THIS RIFLE WILL INVALIDATE THE MANUFACTURERS WARRANTY. THIS INCLUDES ANY ANTI-TAMPER DEVICES FITTED.***

Before leaving the factory this rifle was Q.A. inspected and test fired using Air Arms pellets to check operation and final adjustment.

It was dispatched in a sealed purpose designed box. Air Arms may not be responsible for any damage to the contents or missing items if the box is not original, if it is damaged or the seals are not intact.

Air Arms cannot be held responsible for damage or missing items due to transit damage, mishandling or being tampered with after leaving the factory.

If this rifle is not received in the original box with the seals intact, please examine carefully for any damage, missing tools or documentation.

In the first instance any problems or complaints regarding this product should be referred to the supplier.

The air cylinder is a highly pressurised unit that must not be modified in any way. Serious personal injury may result if this, and the advice below is not followed.

## Important Information (Continued)

Do not pressurise the cylinder if there are any surface abrasions or dents. Contact Air Arms for advice.

Do not store the rifle in places with, or near sources of high temperature such as fires or boilers.

Air Arms recommend using a dry pack filter kit on any hand pumps used to fill our air rifles.

If accessories not manufactured by Air Arms are used on this rifle, Air Arms can not be held responsible for any loss of performance or damage to your rifle. Contact your supplier or Air Arms for any advice on this matter.

Do not store this rifle in a damp place such as garden shed or garage.

Do not store this rifle in a plastic or PVC gun bag without first applying a surface corrosion inhibitor.

Always ensure the loading bolt is fully closed before firing.

Do not attempt to dismantle when pressurised.

Do not pressurize beyond the stated filling pressure (see filling instruction section). Damage caused by such action is not covered by the manufacturers warranty.

Only use clean, filtered and dry compressed air. Never use any other gas, particularly industrial or welding gases such as oxygen, carbon dioxide, acetylene, hydrogen, argon, etc.

If compressed air is being used other than from a diving shop, the inside of the cylinder should be inspected for corrosion at least annually. If in doubt contact Air Arms for advice.

In any event the cylinder should be inspected every two years. Air Arms can provide this service at a reasonable cost.

To maintain this rifle in good working order it should be serviced annually by a competent gunsmith, your supplier may be able to provide this service or contact Air Arms.

A reasonable amount of advice will be provided to enable the end user to service their own rifle, however this is at the discretion of Air Arms and may not be given in all cases.

The velocity of this rifle has been set using Air Arms Field pellets. If any other make or type of pellet is to be used the rifle must be re-tested, to ensure the muzzle energy is within the limits determined by current legislation.

Due to the nature of hand pumps and their relative inefficiency in removing moisture from the compressed air, the chances of corrosion damage to the cylinder and other internal components are increased. Therefore the rifle should be regularly serviced and/or checked for any signs of damage by a competent gunsmith.

**AIR ARMS RESERVE THE RIGHT TO ALTER THE CONSTRUCTION, APPEARANCE OR PERFORMANCE OF ANY PRODUCT WITHOUT PRIOR NOTIFICATION. ALL ILLUSTRATIONS ARE FOR INFORMATION PURPOSES ONLY AND DO NOT NECESSARILY SHOW THE EXACT MODEL THAT WAS PURCHASED.**

## CHECKING VELOCITY

1. Use a reliable chronograph to check velocity, (the formula below requires the reading to be in feet per second - FPS)
2. Use fine measurement scales to weigh the pellet, If scales are unavailable the pellet weight may be stated on the pellet container lid or contact the supplier. (The formula requires the weight to be in grains). To convert from grams to grains multiply by 15.432, i.e. 0.69 grams x 15.432 = 10.65 grains.
3. To find the muzzle energy in ft/lbs use the formula  $(FPS \times FPS \times Grains) / 450240$ , i.e.  $(700 \times 700 \times 10.65) = 5218500$  divide by 450240 = 11.59.

*CURRENT LEGISLATION LIMITS NON-FAC HOLDERS, IN THE UK, TO AIR RIFLES WITH A MAXIMUM OF 12ft/lbs MUZZLE ENERGY.*

**WARNING!** IT IS A VERY SERIOUS OFFENCE TO BE IN POSSESSION OF AN AIR RIFLE THAT YOU ARE NOT CERTIFICATED FOR. CONVICTION CAN RESULT IN CONFISCATION OF YOUR RIFLE, A HEAVY FINE OR IMPRISONMENT, EVEN A COMBINATION OF ALL THREE.

### \*\*\*\*\* LIMITED LIABILITY WARRANTY \*\*\*\*\*

UK Customers only.

*This product is warranted to the retail customer for 3 years from date of purchase against defects in materials and workmanship and is not transferable to any subsequent owner.*

*Proof of purchase is required to receive warranty repairs, retain your purchase invoice and complete the warranty registration online as soon as possible after purchase. The warranty details must show the dealer/supplier name and address and date of purchase.*

***To safeguard your warranty, please ensure regular servicing is carried out as recommended.***

#### **What is covered**

Replacement parts & labour on a 'back to base' basis, return transportation to the consumer (mainland UK only).

#### **What is not covered**

Transportation from the consumer to Air Arms.

Damage caused by misuse, abuse, lack of routine maintenance, transit damage between the dealer/supplier and the consumer or unauthorized disassembly.

Parts subject to normal wear and tear.

Any other consequential cost incurred by the consumer.

Return transportation to consumers outside mainland UK.

No warranty is implied as to the fitness for any particular purpose.

# Operating Instructions

## Cocking

Hold securely in one hand and with the other pull the cocking lever out and to the rear. At the end of the stroke the magazine will index and present a new chamber, also the trigger mechanism will engage. This can be determined by the trigger blade 'kicking' forward at the end of the cocking stroke.

The effort required to cock the gun is quite low so minimal force should be used.



**Note !** It is very important that the cocking lever is pulled back to the correct position. In one positive motion. The magazine indexes to the next pellet position as the bolt is retracted and it is possible for a partial index if the lever is not pulled back fully.

If you find the mechanism has not cocked completely but the magazine has indexed, Re-cock but before closing the bolt, remove the magazine and manually index it back to the empty chamber. Replace the magazine and fire as normal. If this procedure is not followed it is likely that you will load a second pellet into the barrel.

Push the lever back to the forward position. The rifle is now cocked and loaded, treat with caution.

## Mounting/demounting the Magazine & Pellets

### Demounting


Fully cock the rifle, grip the magazine and slide out of the bolt housing without lifting. **Do not** attempt to lift vertically as damage to the indexing spring will result.


To refit the magazine, fully cock the rifle, grip the magazine and slide in the bolt housing applying downward pressure with the fore finger to keep the base of the magazine against the bottom of the slot in the bolt housing. Take care not to damage the indexing spring.



### Loading Pellets

Hold the magazine and drop a pellet into the chamber. Manually index to the next empty chamber and repeat until the magazine is full.





*Be very careful not to damage the indexing spring when demounting or mounting the magazine. Follow the instructions carefully.*

A small drop of oil should be applied to the magazine 'O' ring to keep it moist, and increase its life span.

## Trigger Adjustments

The S510 models all have a two stage unit with adjustment to both stages plus a weight of pull adjustment. It is easy to upset the balance between the two stages and make the trigger inoperable if incorrectly adjusted.

If you have no experience of adjusting two stage triggers seek guidance or leave the trigger as set by the factory.

**Note!** Incorrectly adjusted trigger mechanisms are not covered by the manufacturers warranty. It is not possible to test this rifle with an incorrectly adjusted trigger, therefore all triggers leave the factory with correct adjustment. **WARNING!** Please note that it is possible to stop the safety button working with incorrect trigger adjustment. AN INCORRECTLY ADJUSTED TRIGGER CAN MAKE THE RIFLE UNSAFE TO HANDLE.

## Description Of Operation

The S510 rifles have a true two stage trigger mechanism. This means that as the trigger is pulled the bottom sear gradually disengages with the top sear until the two disengage completely and the rifle goes off. If the pressure on the trigger is released at any point before full disengagement, the bottom sear will automatically return back to full engagement. This type of trigger allows very fine but safe operation because it is the release of the 2nd stage that actually makes the rifle fire. This arrangement is vastly superior to pseudo two stage triggers where the first stage is just a pivoting trigger blade that does not move sears. The down side is that they are more difficult to adjust correctly.


## Adjustment

There are three adjuster screws, A-B-C.

The weight of pull adjuster (A) is located in the front of the trigger guard. Clockwise rotation increases pull weight. If adjusted too far the spring will become coil-bound and prevent trigger operation.

The second stage adjuster (C) is the rear screw located in the trigger blade. This screw determines the exact point that the 2nd stage starts. If the 1st stage screw is incorrectly adjusted this screw may not have any effect.


The first stage adjuster (B) is the front screw located in the trigger blade. This screw determines the length of travel before the 2nd stage starts. Clockwise adjustment reduces the first stage travel.




This rifle is fitted with a manual safety button located in the trigger blade.

To make the rifle safe the button must be pressed until it is flush with the side of the trigger blade.

Please note that it is possible to stop the safety button working with incorrect trigger adjustment.




*With the button pressed in the rifle is safe.*



*With the button out the rifle is now ready to fire.*

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	S420S-2	TRIGGER BLADE - BLACK ANODIZED	1
	S420GS-2	TRIGGER BLADE - GOLD PLATED	
2	S521-2A	SAFETY BUTTON - PART ONE	1
3	S521-2B	SAFETY BUTTON - PART TWO	1
4	S526	SAFETY BUTTON O RING	1
5	S523	BALL BEARING	1
6	S522	SAFETY BUTTON SPRING	1
7	S524	SCREW	1
8	TX432	ADJUSTER SCREW LOCKING PAD	1
9	S421	SCREW	2




## Power Adjuster

The S510 XS is fitted with a power adjuster on the side of the rifle. This can be used to adjust the power at any time by just turning anti-clockwise to increase and clockwise to decrease the power. Adjusting the power between shots will not harm the rifle.



On the left hand side of the rifle is a indicator to help select your most common power settings + = High. - = Low. The marks do not indicate a particular power as this would change depending on the pellets used.



## Filling Instructions


**NOTE!** ONLY USE CLEAN, DRY AND FILTERED COMPRESSED AIR, PREFERABLY FROM A DIVING SHOP. OVER PRESSURIZATION MAY DAMAGE THE CYLINDER BEYOND REPAIR.

First the female part of the filling kit (this was supplied with the rifle) must be fitted to your filling equipment. The female part (S475) has a 1/8th BSP male thread that screws directly into the hose of your pump or bottle.

Next remove the dust cover from the end of your rifle. This is achieved by unscrewing the cover in an anti-clockwise direction.

Once the connector is exposed the female part of the filling kit can be placed on the male and press all the way on making sure that the 'O' rings on the male part are covered.

It is a wise precaution to hold the female part of the connector, during the filling procedure, as shown in the pictures below. This will ensure the female adaptor is located completely over the male part and prevent any accidental dislodging of the connector before you start to refill the cylinder.



What pressure to fill to	250 bar - Filling to a greater pressure will not improve performance
When to refill	Once the rifle has reached 150 bar it is time to refill the cylinder

## Using hand pumps

The procedure for using hand pumps is the same as for bottle. It is more important to turn the female on the gun to lock it in place.

When using the pump it must be remembered that the first few pumps are filling the hose and NOT the gun. When the pressure in the hose equalizes to that in the gun, the gun will start to fill.

It can take some effort to fill the gun using a pump and we recommend using the pump to top up instead of filling from empty.

With the female in place the gun can now be filled.

If the rifle is empty the mechanism will need to be cocked to allow the firing valve to close. If the rifle is not cocked when the bottle is opened or the pump used, the air will past the valve and exhaust through the barrel.

Check that the bleed valve on the filling equipment is closed (turn clockwise to close) then slowly open the main valve on bottle or start using the pump. The pressure in the hose will equalise and then the rifle will start to fill.

If you are filling your rifle from empty there may be some air exhausted through the barrel until the air pressure is sufficient to over come the firing valve spring this will happen at approximately 50 bar (750psi).

The filling pressure of the S510 XS is 250 bar (3625psi). Filling to a higher pressure will not increase either power or number of shots. Over filling will lower the power and may cause irreparable damage to the cylinder.

Once the filling pressure has been reached, close the valve on the bottle or stop pumping, open the bleed valve on the filling kit (to vent the hose, if you do not vent the hose you will not be able to remove the female from the rifle). Now the female connector can be removed from the rifle and end cap (E483BK) can be replaced over the male connector ensuring not to overtighten.

The S510 XS Ultimate Sporter range of rifles are fitted with a pressure indicator mounted on the underside of the rifle just in front of the stock screw. This provides the user with a visual check on the amount of air remaining in the cylinder this indicator should not be used during the filling process as the gauge reaction speed has been slowed to prevent damage whilst filling. After filling the gauge can take several seconds to synchronize with the air in the cylinder. The gauge below shows a guns with just over 100 bar of pressure. Although every gun is slightly different the recommended refill pressure for the S510 XS is 150 bar. **Always use the gauge on the filling kit.**

**Please note: There is not needle on the ultimates sporter gauge, instead there are two zones, green and red. The line between to two replaces the needle on a traditional pressure gauge. More green means more air.**



NOTE: On the front of the cylinder is an engraved warning reading...

READ MANUAL. MFP 250bar. MSP 250bar. DOM \*\*/\*\*/\*\* \*\*.  
INSPECT BI-ANNUALLY.

MFP	=	Maximum Filling Pressure. The pressure is stated.
MSP	=	Maximum Safe Pressure. The pressure is stated.
DOM	=	Date of Manufacture. The date is stated.

## Warning Note Concerning 300 Bar Bottles.

With the advent of the 300 bar bottle it should be noted that care has to be taken when filling your rifle.

The filling procedure described in this manual must be followed to avoid damage to the rifle, particularly the slow opening of the valve on the bottle. Opening the valve quickly will allow up to 300 bar of pressure into the cylinder at once, this could cause serious personal injury or irreparable damage to the cylinder.

## Maintenance

### Fixings

Regularly check the tightness of all fixings. However do not be tempted to over tighten as some parts are made from aluminium and stripped threads may result. Stripped threads are not covered by the manufacturers warranty.

### Barrel

For ultimate accuracy, clean and re-lube the barrel frequently. It is difficult to advise how often is best for every circumstance, but every 250 shots is not too often if the desire is to keep the barrel in the best possible condition.

The correct materials are very important. Air arms only uses products made by Napier. Listed below is the Napier product and a more generally available alternative. If possible use napier for the best results.

CLEANER:	Napier Power Airgun Oil
OIL:	Napier Power Airgun Oil
PULL-THROUGH PAD:	Napier Rifle Clean
PULL-THROUGH LINE:	Napier Power pull through kit

As a rule cleaners and oils intended for shotguns and small/full-bore weapons are not suitable.

1. Cut a piece of line three times the length of your barrel, fold in half and tie ends together.
2. Remove silencer if fitted. Open loading bolt.
3. Feed un-knotted end down barrel from the muzzle end until folded end protrudes out 50 mm.
4. Cut a 100mm length of 'rifle clean' or 100 x 50mm piece of cloth and pass it between the protruding loop. Spray the pad with 'gun cleaner' or white spirit, turn the rifle upside down and pull the line back through the barrel slowly.
5. Repeat steps 2&3 until the pad is clean.
6. Repeat steps 2&3 once more without any cleaner on the pad to dry the barrel.
7. Repeat steps 2&3 once more with the pad sprayed with 'gun oil' or 3 in 1 oil.

IMPORTANT : THE REASON FOR TURNING THE RIFLE UPSIDE DOWN IS TO PREVENT EXCESS CLEANER/OIL FROM PASSING DOWN THE TRANSFER PORT INTO THE FIRING VALVE CHAMBER.

## Lubrication

Lubrication of the internal mechanism is not covered in this handbook. This is best performed by a competent gunsmith or the factory and in any case should not be required until the annual service.

Apply a small dab of grease or oil, on the two pivot points shown in the diagram, and work -in by moving the bolt forwards and backwards. Wipe off excessive grease. Preferred grease is 'napier g95 gun grease' On return from every shooting session, wipe all over the exterior with an oily rag to preserve the surface finish during storage.

A small drop of oil should be applied to the magazine O ring to keep it moist, and increase its life span.



## Stock Adjustments



### Cheek Piece

There are two adjustments available to the cheek piece. The whole assembly can be raised or lower by loosening the screw in the side on the butt stock using a 4mm allen. This allow the cheek piece to be positions at the perfect height for the shooter and scope they are using.

The cheek piece is also mounted on a ball joint at the top of the shaft. Loosening the two screws (access through the slots in the side of the cheek piece) allows the piece to be adjusted by minuet amounts to make the cheek piece as comfortable and exact as possible. Do not over tighten the screws.

### Sling Studs

The Ultimate sporter come fitted with a set of slings studs mounted to the butt stock and fore-end rail. The rail mount can be positioned anywhere along the rail length. To adjust the stud simply loosen the M6 screw inside the stud using a 3mm allen key and slide the stud into the required location then re-tighen the screw. **Test the mount to ensure the screw is tighten enough to hold the weight of the rifle before mounting a sling. If the stud is too loose it may slide out of the rail during use.**




## Butt Pad

The butt pad has two adjustments available.

It can be adjusted to allow up and down movement for a higher or lower head position. This is done by loosening the screw in the middle of the pad and sliding into place then retightening the screw.

The second adjustment allow the length of the butt to be extended, this is achieved by adding spacers between the butt pad and the stock. With the pad slid up and down the screws that fix it to the wood can be accessed to allow extra spacers to be fitted. Please note that depending on the number or size of spacers required you may have to obtain longer screws.



## Removing The Stock

To remove the stock from the action first ensure the gun is not cocked or loaded. Using a 5mm allen unscrew the bolt holding the stock to the action. This bolt is situated between the trigger guard and the gauge on the underside of the rifle. Remove the bolt and washer to allow the action to lift out of the stock.


When refitting take care not to over tighten the bolt and crush into the wood. Make sure the washer is present to avoid damage.

# Exploded Diagrams

ITEM NO.	PART NUMBER	DESCRIPTION	QTY	ITEM NO.	PART NUMBER	DESCRIPTION	QTY	ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	S507-R	FIRING VALVE BODY	1	36	S522	COMPRESSION SPRING	1	73	S322	M4 X 12 CSK SKT	1
2	S500H-R	BOLT HOUSING	1	37	S528	7/64" BALL BEARING	1	81	E127	3 X 7.8 ROLLER	1
3	S932-2	VALVE SEAT	1	38	S610-HP-R	TRANSFER PORT BUSH HP	1	82	E144	3 X 23.8 ROLLER	1
4	S934	M6 X 6 SKT SET CONE PT	1	39	S382H-SL	FRONT CLAMP	1	94	S130	COCKING ARM PIVOT BLOCK	1
6	S966	8 X 1.5 NBR70	1	40	E483BK	END CAP	1	95	S125	COCKING ARM	1
7	S960	2 X 1.5 NBR70	2	41	S472	MALE CONNECTOR	1	96	TX227	BUFFER	1
9	S337	10 X 1.5 NBR 70	1	42	S950L-R	CYLINDER LONG	1	97	E160	M3 CRINKLE WASHER	2
10	S327	BS005 NBR90	1	43	S600H-SL	BARREL TUBE - EXTRA SL	1	98	S542	SIDE LEVER BUSH	1
11	S484H	20 X 1.5 NBR70	1	44	FP134	THREAD PROTECTOR	1	99	S264	COCKING LINK	1
12	RN219-9	BS011 NBR70	1	45	S491-R	FIRING VALVE BODY	1	100	S541	LOADING BOLT BEARING	1
13	S427	6 X 1 NBR70	1	46	S473	FILLING VALVE	1	101	S541-1	BEARING SHIM	1
14	S536	BS008 NBR70	1	47	S319	COMPRESSION SPRING	1		S501-SL	BOLT HSE BUSH - .22	
16	S140	4 X 2 NBR70 9.22 & .25)	1	48	S912	BONDED SEAL	1	102	S502 -SL	BOLT HSE BUSH - .177	1
	S142	BS102 NBR70 (.177)		49	S928	M4 X 6 SKT BTN	1		S504-SL	BOLT HSE BUSH - .25	
17	S484	12 X 1.5 NBR70	1	50	S946	M2.5 X 16 SKT CAP	2	103	RN113	M5 X 6 SKT SET CUP PT	2
18	S936-25	REGULATOR HOUSING - LARGE	1	51	S402AH-R	BARREL SEAL HOLDER HP - .22	1	104	S505	MAGAZINE RETAINING CLIP	1
	S936	REGULATOR HOUSING - SMALL			S402BH-R	BARREL SEAL HOLDER HP -.177		105	RN193	M3 X 6 SKT BTN	2
19	S342	15 X 2 NBR90	3	52	E222	BUSH	2	106	S550-R	SIDE PLATE ADJ HP	1
20	S962A-150	REGULATOR 150 bar	1	53	TX239	M3 X 3 SKT SET FT PT	1	107	S515A	INDEXING POST ASSY	1
	S962A-165	REGULATOR 165 BAR		54	S303	M3 X 3 SKT SET FT PT	1	108	S560	CAM PLATE	1
21	S938	REGULATOR RETAINER	1	55	S517	3/32 x 1/4 DIN6325	1	109	S565	M3 X 8 SKT CAP	3
22	S346	M3 X 50 SKT CAP (.25)	2	56	S474	12 X 2 NBR70	2		S555A-US	MAGAZINE - .22 (10 SHOT)	
	S920-7	M3 X 25 SKT CAP (.177 & .22)		57	TX228	M4 X 4 SKT SET FT PT	2		S555B-US	MAGAZINE - .177 (10 SHOT)	
23	S836	23 X 2.5 NBR90	4	58	S471	SINTERED FILTER	1	110	S555C-US	MAGAZINE - .25 (10 SHOT)	2
24	S837	23 X 2.5 BACKUP RING	2		S401A-BO	BARREL .22			S554-US	MAGAZINE - .25 (5 SHOT)	
25	S370-2-R	FIRING VALVE	1	59	S401B-BO	BARREL .177	1		S557-US	MAGAZINE - .22 (5 SHOT)	
26	S940	VALVE STEM NUT	1		S401J-BO	BARREL .25			S558-US	MAGAZINE - .177 (5 SHOT)	
27	S942	COMPRESSION SPRING	1	60	PS224	BAFFLE	5	111	S600-3	BARREL TUBE SUPPORT	1
28	S331	COMPRESSION SPRING	1	61	S133	SHROUD INSERT	1	112	RN219-7	BS012 NBR70	2
30	S340-R	GUIDE ROD	1	62	S530	MAIN SPRING GUIDE	1	113	E880-6	BS0031-16 NBR70	2
32	S944	GUIDE ROD NUT	1	63	S356H	M4 X 5 MODIFIED	1	114	S952	SPRING BAFFLE	1
33	S520H-R	STRIKER HP	1	67	S355H-SL	M4 X 12 MODIFIED	1				
34	S508-R	POWER ADJUSTER	1	69	RN102A	M3 X 16 SKT CAP	4				
	FP121	BARREL SEAL - .177		70	S640AT	GAUGE MOUNT	1				
35	S538	BARREL SEAL - .22	1	71	S968	M5 X 16 SKT BTN	1				
	FP122	BARREL SEAL - .25		72	S645-2	INDICATOR GAUGE	1				

Items not shown in the above list:


### S475 - Filling adaptor



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	S507-R	FIRING VALVE BODY	1	36	S946	M2.5 X 16 SKT CAP	2	88	S130	COCKING ARM PIVOT BLK	1				
2	S500H-R	BOLT HOUSING HP ADJ	1	37	S402AH-R	BARREL SEAL HOLDER - .22	1	89	TX227	BUFFER	1				
3	S932-2	VALVE SEAT	1		S402BH-R	BARREL SEAL HOLDER - .177	1	90	E160	M3 CRINKLE WASHER	2				
4	S934	M6 X 6 SKT SET CONE PT	1	38	S337	10 X 1.5 NBR 70	1	91	S542	SIDE LEVER BUSH	1				
5	S966	8 X 1.5 NBR70	1	39	E222	BUSH	2	92	S264	COCKING LINK	1				
6	S960	2 X 1.5 NBR70	2	40	S331	COMPRESSION SPRING	1	93	S140	4 X 2 NBR70 - .22 & .25	1				
7	S936-25	REGULATOR HOUSING - LARGE	1	41	TX239	M3 X 3 SKT SET FT PT	1		S142	BS102 NBR70 - .177	1				
	S936	REGULATOR HOUSING - SMALL	1	42	S517	3/32 x 1/4 DIN6325	1	94	S541	LOADING BOLT BEARING	1				
8	S342	15 X 2 NBR90	3	43	S474	12 X 2 NBR70	2	95	S355H-SL	M4 X 12 MODIFIED	1				
9	S962A-150	REGULATOR 150 bar	1	44	S327	BS005 NBR90	1	96	S541-1	BEARING SHIM	2				
	S962A-165	REGULATOR 165 bar	1	45	S484H	20 X 1.5 NBR70	1		S501-SL	BOLT HSE BUSH - .22	1				
10	S938	REGULATOR RETAINER	1	46	TX228	M4 X 4 SKT SET FT PT	2	97	S502 - SL	BOLT HSE BUSH - .177	1				
11	S346	M3 X 50 SKT CAP	2	47	S471	SINTERED FILTER	1		S504-SL	BOLT HSE BUSH - .25	1				
	S920-7	M3 X 25 SKT CAP	1		FP121	BARREL SEAL - .177	1	98	E127	3 X 7.8 ROLLER	1				
12	S836	23 X 2.5 NBR90	4	48	S538	BARREL SEAL - .22	1	99	E144	3 X 23.8 ROLLER	1				
13	S837	23 X 2.5 BACKUP RING	2		FP122	BARREL SEAL - .25	1	100	RN113	M5 X 6 SKT SET CUP PT	2				
14	S370-2-R	FIRING VALVE HP	1		S401A-BO	BARREL - .22	1	101	S505	MAGAZINE RETAINING CLIP	1				
15	S940	VALVE STEM NUT	1	49	S401B-BO	BARREL - .177	1	102	RN193	M3 X 6 SKT BTN	2				
16	S942	COMPRESSION SPRING	1		S401J-BO	BARREL - .25	1	103	S550-R	SIDE PLATE ADJ HP	1				
17	S340-R	GUIDE ROD - REGULATED	1		S710-EUS-177	MODERATOR - .177	1	104	S515A	INDEXING POST ASSY	1				
19	S944	GUIDE ROD NUT	1	50	S710-EUS-22	MODERATOR - .22	1	105	S560	CAM PLATE	1				
20	S520H-R	STRIKER HP	1		S710-EUS-25	MODERATOR - .25	1	106	S565	M3 X 8 SKT CAP	3				
21	S508-R	POWER ADJUSTER	1	51	S530	MAIN SPRING GUIDE	1		S555A-US	MAGAZINE - .177 (10 SHOT)					
22	E880-6	BS0031-16 NBR70	2	52	S356H	M4 X 5 MODIFIED	1		S555B-US	MAGAZINE - .22 (10 SHOT)					
23	S522	COMPRESSION SPRING	1	53	RN102A	M3 X 16 SKT CAP	4	107	S555C-US	MAGAZINE - .25 (10 SHOT)					
24	S528	7/64" BALL BEARING	1	54	S303	M3 X 3 SKT SET FT PT	1		S558-US	MAGAZINE - .177 (5 SHOT)	1				
25	S610-HP-R	TRANSFER PORT BUSH HP	1	55	S640AT	GAUGE MOUNT	1		S557-US	MAGAZINE - .22 (5 SHOT)					
26	S382H-SL	FRONT CLAMP	1	56	RN219-9	BS011 NBR70	1		S554-US	MAGAZINE - .25 (5 SHOT)					
27	E483BK	END CAP	1	57	S427	6 X 1 NBR70	1	108	S484	12 X 1.5 NBR70	1				
28	S472	MALE CONNECTOR	1	58	S536	BS008 NBR70	1	110	S952	SPRING BAFFLE	1				
29	S950M-R	CYLINDER MEDIUM	1	59	S968	M5 X 16 SKT BTN	1								
30	S735-EX	BARREL TUBE	1	60	S645-2	INDICATOR GAUGE	1								
31	S491-R	FILLING VALVE BODY	1	61	S322	M4 X 12 CSK SKT	1								
32	S473	FILLING VALVE	1		S540A - SL	LOADING BOLT - .177	1								
33	S319	COMPRESSION SPRING	1	86	S540B-SL	LOADING BOLT - .22	1								
34	S912	BONDED SEAL	1		S540C-SL	LOADING BOLT - .25	1								
35	S928	M4 X 6 SKT BTN	1	87	S125	COCKING ARM	1								


Items not shown in the above list:

### S475 - Filling adaptor




BOM ID	Part No.	Description	Qty
1	S676-PT1	MAIN STOCK BODY	1
2	S676-PT2	CHEEK PIECE	1
3	E335	CHEEK PIECE RAIL	1
4	S750	No.6 x 0.50	6
5	E340	RAIL NUT	2
6	JT416	M5 X 18 SKT BTN	2
7	RN431	M5 WASHER	7
8	S770-PT2	CHEEK PIECE TOP CLAMP - PT 2	1
9	S770-PT1	CHEEK PIECE TOP CLAMP - PT1	1
10	RN430	M5 X 12 SKT BTN	2
11	S740	CHEEK PIECE PILLAR	1
12	S780	No.8 x 1.25	2
13	S775	CHEEK PIECE PILLAR BOTTOM PLATE	1
14	E425	ADJUSTER LOCKING BUSH	1
15	PS418	M5 X 20 SKT CAP	1
16	CZ028-1	4mm SPACER	1

BOM ID	Part No.	Description	Qty
17	CZ080-2	BUTT PAD BACKING PLATE	1
18	S641	M5 X 25 SLOTTED CH HD	2
19	CZ080-1	BUTT PAD	1
20	CZ080-3	M5 X 16 SLOTTED CH HD	1
21	CZ080-4	LOCKING PLATE	1
22	S685	ROLLER NUT	2
23	S755	REAR SLING MOUNT	1
24	S655	M6 WASHER	1
25	S625	M6 X 40 SKT CAP	1
26	S640R-BK	STOCK RING	1
27	S765	M6 X 6 SKT SET FT PT	1
28	S760-PT1	FRONT SLING MOUNT - PT1	1
29	S760-PT2	FRONT SLING MOUNT - PT2	1
30	S970	M3.5 X 16 CH HD TORX	1
31	S745	RAIL - ULTIMATE SPORTER	1



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	S310-SL-R	STRIKER BODY	1	15	S311	COMPRESSION SPRING	1
2	S322	M4 X 12 CSK SKT	1	16	S522	COMPRESSION SPRING	1
3	S313	TRIGGER CHASSIS	1	17	TX381	M5 X 6 SKT SET CONE PT TUFF LOC	1
4	S320-2	TOP SEAR	1	18	S524	M3 X 4 SKT SET CONE PT	2
5	S325-2	MIDDLE SEAR	1	19	S495	TOP SEAR SPRING	1
6	S321-2	BOTTOM SEAR	1	20	S420S-2	TRIGGER BLADE	1
7	S496	M3 X 6 SKT CAP	1	21	S421	M3 X 10 SKT SET FT PT	2
8	S316	M4 X 25 SKT CAP	1	22	TX432	ADJUSTER SCREW LOCKING PAD	1
9	TX460	M4 X 12 SKT CAP	1	23	S523	3/32" BALL BEARING	1
10	TX236	M4 X 16 SKT CAP	1	24	S521-2A	SAFETY BUTTON - PART ONE	1
11	RN106	M3 X 6 CSK SLOT	2	25	S521-2B	SAFETY BUTTON - PART TWO	1
12	S326	2 X 11.8 ROLLER	3	26	S526	3 X 1 SIR70	1
13	TX398	3 X 11.8 ROLLER	1	27	S314	TRIGGER GUARD	1
14	S319	COMPRESSION SPRING	1	28	S318	COVER PLATE	1



## Warranty (UK Only)

The Air Arms warranty covers repairs free of charge if the item is up to 3 years old, from date of purchase (UK only). The warranty covers faulty materials and workmanship, not reasonable wear and tear. The warranty applies to items purchased from new; proof of purchase is required. This cover is not transferable, therefore it applies to the original purchaser only. Please retain your receipt and register the warranty online at: [www.air-arms.co.uk/warranty-submission](http://www.air-arms.co.uk/warranty-submission).

***To safeguard your warranty, please ensure regular servicing is carried out as recommended.***

### What is covered

Replacement parts and labour. Return transportation to the consumer (UK mainland only).

### What is not covered

Transportation from the consumer to Air Arms.

Damage caused by misuse, abuse, disassembly or lack of routine maintenance/servicing.

No warranty is implied as to the fitness for any particular purpose. Return transportation to consumers outside the UK mainland. Any rifle with serial number removed or altered.

Please visit [www.air-arms.co.uk](http://www.air-arms.co.uk) to register your rifle and details or scan the QR code below.



## Air Arms

Unit 5-6, Hailsham Industrial Park,  
Diplocks Way, Hailsham,  
East Sussex BN27 3JF.

Tel: 01323 845853

Website: [www.air-arms.co.uk](http://www.air-arms.co.uk)

Email: [general@air-arms.co.uk](mailto:general@air-arms.co.uk)